


Actuator LA25  
IC Basic  
*Connection diagram*


# Connection diagram

25xxxxxxxxxx3x1x=xxxxx18xxxxxx



Please be aware that if the power supply is not properly connected, you might damage the actuator!

# I/O Specifications

Input/Output	Specification	Comments
Description	<p>Easy to use interface with integrated power electronics (H-bridge).</p> <p>The version with "IC option" cannot be operated with PWM (power supply).</p> <p>See connection diagram, figure above</p>	 <p>H-Bridge</p>
Brown	<p>12-24VDC + (VCC)</p> <p>Connect Brown to positive</p> <p>12V ± 20% - max. 5A depending on load</p> <p>24V ± 10% - max. 2.5A depending on load</p> <p>12V, current limit 8A</p> <p>24V, current limit 5A</p>	<p>Note:</p> <p>Do not change the power supply polarity on the brown and blue wires!</p> <p>Power supply GND (-) is electrically connected to the housing</p> <p>If the temperature drops below 0°C, all current limits will automatically increase to 9A for 12V and 6A for 24V</p>
Blue	<p>12-24VDC - (GND)</p> <p>Connect Blue to negative</p> <p>12V ± 20% - max. 5A depending on load</p> <p>24V ± 10% - max. 2.5A depending on load</p> <p>12V, current limit 8A</p> <p>24V, current limit 5A</p>	
Red	Extends the actuator	<p>On/off voltages:</p> <p>&gt; 67% of <math>V_{IN}</math> = ON</p> <p>&lt; 33% of <math>V_{IN}</math> = OFF</p> <p>Input current: 10mA</p>
Black	Retracts the actuator	
Green	Endstop signal out	<p>Output voltage min. <math>V_{IN} - 2V</math></p> <p>Source current max. 100mA</p> <p>Endstop signals are NOT potential free.</p>
Yellow	Endstop signal in	
Violet	Not to be connected	
White	Not to be connected	



- Current cut-offs should not be used as stop function! This might damage the actuator. Current cut-offs should only be used in emergencies!
- Current cut-off limits are not proportional with the load curves of the actuator. This means that the current cut-offs cannot be used as load indicator.
- There are tolerances on the spindle, nut, gear wheels etc. and these tolerances will have an influence on the current consumption for the specific actuator.

---

**Terms of use**

The user is responsible for determining the suitability of LINAK products for specific application. LINAK takes great care in providing accurate and up-to-date information on its products.

However, due to continuous development in order to improve its products, LINAK products are subject to frequent modifications and changes without prior notice. Therefore, LINAK cannot guarantee the correct and actual status of said information on its products.

While LINAK uses its best efforts to fulfill orders, LINAK cannot, for the same reasons as mentioned above, guarantee the availability of any particular product. Therefore, LINAK reserves the right to discontinue the sale of any product displayed on its website or listed in its catalogues or other written material drawn up by LINAK.

All sales are subject to the Standard Terms of Sale and Delivery for LINAK. For a copy hereof, please contact LINAK.