




Actuator LA33
IC Basic
Connection diagram


Connection diagram

33XXXXXXXXXXXX3XXX=XXXXXXXX1XXXXX



Please be aware that if the power supply is not properly connected, you might damage the actuator!

I/O Specifications

Input/Output	Specification	Comments
Description	Easy to use interface with integrated power electronics (H-bridge). The version with "IC option" cannot be operated with PWM (power supply). See connection diagram, figure above	
Brown	12-24VDC + (VCC) Connect Brown to positive 12V ± 20% 24V ± 10% 12V, max. 13A - current cut off @ 15A 24V, max. 9A - current cut off @10A	Note: Do not change the power supply polarity on the brown and blue wires! Power supply GND (-) is electrically connected to the housing If the temperature drops below 0°C, all current limits will automatically increase to 20A for 12V and 15A for 24V
Blue	12-24VDC - (GND) Connect Blue to negative 12V ± 20% 24V ± 10% 12V, max. 13A - current cut off @ 15A 24V, max. 9A - current cut off @10A	
Red	Extends the actuator	On/off voltages: > 67% of V_{IN} = ON < 33% of V_{IN} = OFF Input current: 10mA
Black	Retracts the actuator	
Green	Endstop signal out	Output voltage min. V_{IN} - 2V Source current max. 100mA Endstop signals are NOT potential free. Endstop signals can be configured with BusLink software according to any position needed When configuring virtual endstop, it is not necessary to choose the position feedback EOS and virtual endstop will work even when feedback is not chosen
Yellow	Endstop signal in	
Violet	Not to be connected	
White	Not to be connected	



- Current cut-offs should not be used as stop function! This might damage the actuator. Current cut-offs should only be used in emergencies!
- Current cut-off limits are not proportional with the load curves of the actuator. This means that the current cut-offs cannot be used as load indicator.
- There are tolerances on the spindle, nut, gear wheels etc. and these tolerances will have an influence on the current consumption for the specific actuator.

Terms of use

The user is responsible for determining the suitability of LINAK products for specific application. LINAK takes great care in providing accurate and up-to-date information on its products.

However, due to continuous development in order to improve its products, LINAK products are subject to frequent modifications and changes without prior notice. Therefore, LINAK cannot guarantee the correct and actual status of said information on its products.

While LINAK uses its best efforts to fulfill orders, LINAK cannot, for the same reasons as mentioned above, guarantee the availability of any particular product. Therefore, LINAK reserves the right to discontinue the sale of any product displayed on its website or listed in its catalogues or other written material drawn up by LINAK.

All sales are subject to the Standard Terms of Sale and Delivery for LINAK. For a copy hereof, please contact LINAK.