



How to pair a LINAK® Wireless control box



Move within two meters of the bed / application.




Enter Direct Pairing Mode by activating key 1 and magnet in 3 seconds.



Release key and magnet and move closer to control box until buzzer frequency change from slow to fast.



Confirm pairing by pushing key 1



Double confirmation beep - Pairing OK



How to pair