



# Bed Control™ App Data sheet

# Bed Control™ App

The Bed Control™ App is developed for adjustment of leisure beds equipped with LINAK® motors and the LINAK Bluetooth® Adapter or the TWINDRIVE® TD4/TD5 system. The app features the same functions as our selection of hand controls and allows the users to adjust their beds via their tablets or smartphones. An onboarding flow will help the user get started and make the app fit for his/her bed. The app will graphically adjust to the connected product, e.g. when connected to the TD4/TD5 Advanced, four memory positions will be shown on the screen. The Bed Control™ App can also be customised to reflect your brand.



## Features:

- Can control the back, leg, neck and footrest individually up and down
- Simultaneous drive (two motors at a time)
- Control of massage
- Bed selector (for single bed, double bed and double bed synchronized)
- Turn the Under Bed Light on/off
- Alarm function with movement or massage
- Four memory positions (if supported by the product)
- Works via Bluetooth® Low Energy Technology
- Available in eight languages: English, Danish, Spanish, French, Italian, Korean, Swedish and German

## Options:

- Customised look of the app (background colour, logo and links)
- Tailor your own bed app with unique features using the LINAK Software Development Kit

## Usage:

- Compatible with CBD6DC and LINAK Bluetooth® Adapter
- Compatible with TWINDRIVE® TD4/TD5 series
- Compatible with LA18 IC Standard and LA18 IC Advanced
- Compatible with KA20 IC
- Compatible with newer iOS and Android-based smartphones/tablets with Bluetooth® Low Energy.



Check the minimum requirement for iOS/Android version in the relevant app store.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG Inc. and any use of such marks and logos by LINAK A/S is under license.

## FAQ

<b>Who owns the data entered in / collected by the app?</b>	<b>Can I delete all data collected?</b>	<b>Who can access/use the data?</b>
The user owns all data entered in / collected by the app.	Yes, delete the app to delete all data. Go to settings on your device to delete the app. If you re-install the app, you need to pair the app and the bed again to be able to control the bed via the app.	The data can only be accessed in your device. LINAK does not access or use any data entered in the app (such as favourite positions, height, weight and gender) or collected by the app (statistics).

---

LINAK® accepts no responsibility for possible errors or inaccuracies in catalogues, brochures, and other material. LINAK reserves the right to change its products without prior notice. LINAK cannot guarantee product availability and reserves the right to discontinue the sale of any product. The user is responsible for determining the suitability of LINAK products for a specific application. All sales are subject to the 'Standard Terms of Sale and Delivery', available on LINAK websites.

LINAK and the LINAK logotype are registered trademarks of LINAK A/S. All rights reserved.

FOR MOUNTING INSTRUCTIONS AND GUIDANCE IN USAGE, PLEASE SEE THE RELEVANT USER MANUAL